



RZNC-05 Series


CNC Handle Controller

Emergent Recover

Fax:+86-10-57130422
Mob:+86-13581806922
[Http://www.richnc.com](http://www.richnc.com)
Skype:wwwrichnccom
E-mail:richnc@hotmail.com


Remark: please must sure read this before you want to recover the DSP.(if not, the DSP would not be repaired by yourself and must send to manufacturers).

1. Power off the DSP(handle controller)
2. Press the "OK" key then power on with the computer.(please connect with the computer)
3. Leave your finger(the "OK" key) when the DSP(handle controller) screen is lighting
4. If you correct done , the DSP controller screen will show you this:



5. Please select the "Emergent program" and press "ok" key

Remark: you can press the "X-" to move the cursor.




6. Press the "ok" key the DSP will formatting all of parameters, like this




Remark:

Please copy all of your controller parameters onto paper before you want recover the controller.because this operation will format all of the parameters in the controller.


7. The DSP will show you this after format



8. Please select the "Normal Version".



9. Please press the "ok" key




Remark:

This picture was show the controller some information , they are different with different model of products.

RichNC Company Brand Processor Model

Must be this
"LOGO"



Internal Info

Normal Version

Product Mode ID

10. If all of done as same as the above , please power off and power on. The DSP will good work again.

If have any matters please never updata the controller, contact the Mr.Jery first!!!